

MERCEDES SPRINTER

from 2018

R.W.D. (907)

**FRONT RIGHT
ELECTRIC DOOR**

7495-119

7495-1191

Using Original Vehicle Remote's Key

7495-1192

Including Remote Control (2 Pieces)


- DUE TO AN UNANNOUNCED CHANGES IN THE VEHICLES, BEFORE ORDERING CHECK IF THE INSTALLATION DRAWINGS AND MATERIAL SUPPLY FITS THE SPECIFIC VEHICLES.
- ALEX ORIGINAL RESERVE THE RIGHTS TO MAKE CHANGES IN ITS PRODUCTS WITHOUT ADVANCE NOTICE.



MERCEDES SPRINTER

from 2018 (907)

FRONT RIGHT ELECTRIC DOOR INSTALLATION INSTRUCTIONS



FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



REQUIRED TOOLS

T25

Ø8mm (5/16")
Ø10mm (3/8")
Ø13mm (1/2")

Ø3.5mm (1/8")
Ø6.5mm (1/4")
Ø12mm (1/2")


Ø38mm (1 1/2")

Ø8mm (5/16")
Ø10mm (3/8")
Ø13mm (1/2")
Ø17mm (11/16")
Ø19mm (3/4")

SCREW DRIVER PHILIPS
SCREW DRIVER FLAT
SCREW DRIVER T20

FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018




FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018





1A





- A REMOVE COVER**
- B REMOVE ORIGINAL BOLT**
- C REMOVE THE FRONT PART OF HANDLE**
- D REMOVE ORIGINAL BOLT**
- E REMOVE THE HANDLE**

FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018





- A** LOCATE TEMPLATE TO ORIGINAL HOLE
- B** DRILL 4 HOLES Ø3.5 & ENLARGE TO Ø6.5
- C** REMOVE TEMPLATE



FRONT RIGHT ELECTRIC DOOR



MERCEDES SPRINTER from 2018



- A** LOCATE THE CONTRA PLATE FROM THE INSIDE USING 2 BOLTS M6x25 + SELFLOCKING NUTS
- B** LOCATE DOOR BRACKET PLATE USING 3 BOLTS M6x25 + SELFLOCKING NUTS

2 BOLTS M6x25
+ SELFLOCKING NUTS

A




B

3 BOLTS M6x25
+ SELFLOCKING NUTS

DOOR BRACKET
PLATE
P.N. 2296-541






FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018




FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



DISCARD







FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



A DISCARD ORIGINAL BOLT.
INSTALL MAIN DRIVE BRACKET
USING BOLT M8x35, WASHER
& SPACER Ø19xØ8.5x15mm



B INSERT A PIN TO POSITION
THE MAIN DRIVE BRACKET


C SCREW USING
6 SCREWS 5x19 (S.D.)

3 BOLTS M8x35
+ SELFLOCKING NUTS
+ WASHERS

BOLT M6x50
+ SELFLOCKING NUT
(SEE PHOTO 8)

FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



12

- A** LOCATE TEMPLATE
DRILL A HOLE Ø3.5
& ENLARGE TO Ø38

TEMPLATE
P.N. 2296-546

- A**
DRILL A HOLE Ø3.5
& ENLARGE TO Ø38

- B** REINSTALL
THE DOOR COVER PANEL


- C** REINSTALL ORIGINAL
CABLE TO DOOR PANEL
HANDLE

- D** FIX DOOR BRACKET
COVER USING
2 SCREWS

DOOR BRACKET
COVER
P.N. 2296-548


2 SCREWS 3x18

13



FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



DOOR ADJUSTMENT:

STEP 1:

AFTER CONNECTING THE ELECTRIC SYSTEM, PRESS THE DRIVER OPERATING SWITCH TO CLOSE POSITION TILL THE ELECTRIC MOTOR STOPS.

STEP 2:



PULL THE DOOR TO CLOSE POSITION THEN ADJUST THE CONNECTING ROD ACCORDING TO THE PICTURE.

STEP 3:

CONNECT THE ROD TO THE DOOR BRACKET.

FRONT RIGHT ELECTRIC DOOR

MERCEDES SPRINTER from 2018



FRONT RIGHT ELECTRIC DOOR


MERCEDES SPRINTER from 2018



19

REMOTE CONTROL

ELECTRONIC CONTROL BOX



MERCEDES SPRINTER from 2018

